

DIRT LATE MODELS

SWING ARM CHASSIS

Adjustment Recommendation Sheet

Fast Tracks Conditions

(Extremely Rough or Heavy Conditions Requires 125 psi. in all 4 corners)

LEFT FRONT

E/C 4077-5/6-2 (DOUBLE ADJUSTABLE SHOCKS)

50 psi.

(Gas Pressure)

Rebound position #7
Rebound position #8
Comp. 4 clicks off full stiff
Comp. 4 clicks off full stiff

(Flat Tracks)
(High Bank Tracks)
(Flat Tracks)
(High Bank Tracks)

RIGHT FRONT

E/C4077-5/6-2

50 psi.

Rebound position # 7
Rebound position # 7
Comp. 2 clicks off full stiff
Comp. 1 click off full stiff

LEFT REAR

E/C 4096-4/6-3 (DOUBLE ADJUSTABLE SHOCKS)

Shocks behind rear axle

50 psi.

(Gas Pressure)

Rebound position #8
Rebound position #9
Comp. 2 clicks off full stiff
Comp. 2 clicks off full stiff

(Flat Tracks)
(High Bank Tracks)
(Flat Tracks)
(High Bank Tracks)

RIGHT REAR

E/C4097-4.5/5-1

50 psi.

Rebound position # 1
Rebound position # 1
Comp. 2 clicks off full stiff
Comp. 2 click off full stiff



1698 Midwest Blvd. Indianapolis, IN 46214
317.271.7100 | www.advancedracing.net